

SILENT SENTINEL ARE SPECIALISTS IN LONG RANGE
OPTICAL SENSORS INCLUDING BOTH COOLED AND
UNCOOLED THERMAL CAMERAS

FIXED MODUM ETS SOFTWARE GUIDE

Version: V1.6

Date: 05/10/2020



Conditions of Release

Silent Sentinel Limited reserves all right. This manual includes texts, pictures, diagrams, and other contents belonging to Silent Sentinel Limited. Without the written permission, no one shall copy, photocopy, translate or disseminate all or part of this manual.

This manual is to be used as a guide. The photos, graphics, diagrams, and illustrations provided in the manual are only used for explanation, which may be different from the specific product. Please refer to the actual product. We try our best to make sure all the contents in this manual are accurate. We do not provide any representations or warranties in this manual.

If you need the latest version of this manual, please contact us. Silent Sentinel recommends that you use this manual under the guidance of professionals.

Record of Changes

Issue	Date	Details of Changes	Amended by
V1.0	22/06/2020	Initial draft	Xueer Lin
V1.1	25/06/2020	Add context about text size, login pwd, BB-R, NUC, EdgeVis pwd	Xueer Lin
V1.2	30/06/2020	Modified context for release of v1.84.3-devA	Xueer Lin
V1.3	03/07/2020	Add license related content. Add pre-configuration instructions. Add common trouble shooting.	Xueer Lin
V1.4	06/07/2020	Formatting, spelling.	Xueer Lin
V1.5	14/07/2020	Update license request form	Xueer Lin
V1.6	05/10/2020	Add Thermal-only content	Xueer Lin

Table of Contents

Conditions of Release	1
Record of Changes.....	2
1. Prerequisites.....	5
2. Introduction.....	5
3. System Overview	5
4. Network Architecture.....	5
5. Junction Enclosure IP address	5
6. Computer Requirements.....	6
7. ETS (Evaluated Temperature Screening) Software Operation	6
7.1. First-time Setup	9
7.1.1. Import License	9
7.1.2. Open the Software	9
7.1.3. Admin Login & Full Control Panel.....	11
7.1.4. Select Thermal Camera Type.....	11
7.1.5. Offset and Alignment Nudging (Dual-light system only).....	12
7.1.6. Set Region of Interest (ROI).....	14
7.1.7. Set background image.....	16
7.2. Home Screen Brief Introduction.....	17
7.3. Basic Operations.....	19
7.3.1. Set Blackbody Area.....	19
7.3.2. Set Region of Interest (ROI).....	19
7.3.3. Change Text size	20
7.3.4. Change log in password.....	20
7.3.5. Set IP Address for Video Source	21
7.3.6. Full screen display	22
7.3.7. Disable Blackbody Calibration (not recommended).....	22
7.3.8. Change Blackbody Temperature (not recommended).....	22
7.3.9. Remove Blackbody Error	24
7.3.10. Configure Audible Alarm	24
7.3.11. Configure data logging/saving.....	25
7.3.12. Check logged data	25
7.3.13. Check alarm snapshots.....	26
7.3.14. Change temperature threshold.....	27
7.3.15. Configure Face Detection Settings	27
7.3.16. Change Temperature Scale.....	28
7.3.17. Face Detection Data Overlay Options	29

7.3.18.	Configure Blackbody Obstruction Detection.....	30
7.3.19.	Configure thermal Non-Uniformity Correction (NUC).....	30
7.3.20.	Auto focus the thermal lens	31
7.3.21.	Change colour palette	31
7.3.22.	Temperature Compensation Mode.....	31
7.3.23.	Clear data (error/thumbnails)	31
7.3.24.	Take screenshot.....	32
7.3.25.	Hide thumbnail display.....	32
7.4.	Advance configuration	34
7.4.1.	Use Modbus for alarm output.....	34
7.4.2.	Use of EdgeVis	35
7.4.3.	View message log	36
7.4.4.	Advanced parameter control	36
8.	Common problems and solutions	37
8.1.	Face detection not working.....	37
8.2.	Face bounding box lagging	37
8.3.	Thermal-only detection picking up non-face objects (e.g. arms, blackbody...)	37
	Appendix A – Configure a Static Laptop IP Address	39

1. Prerequisites

Please refer to the help desk to ensure you have the latest version of the software applications and user guides:

<https://silentsentinelhelp.helpdocs.com/fixed-modum>

2. Introduction

The aim of this document is to detail the steps required to configure and operate the SS ETS (Silent Sentinel Evaluated Temperature Screening) system and associated capability.

3. System Overview

The entire ETS System has several components required to provide its entire capability as follows:

Local Viewing. The local viewing capability allows the local operation and detection of objects from a 2 to 5 meter range. A local operator is deployed at the front end with the equipment providing a first layer mechanism of viewing and alerting. The local viewing equipment consists of:

- MODUM Camera (Thermal & HD Daylight);
- Equipment Enclosure;
- Local Viewing Laptop running the Intelligent Screening Software;
- Blackbody Temperature Sensor (place at 2-5 meters away from the cameras);
- Transportable Equipment Platform / Housing.

4. Network Architecture

Figure 1 shows the system architecture/ connectivity of the capability.




Figure 1 ETS System Architecture

5. Junction Enclosure IP address

Junction Enclosure IP addresses (for all Junction Enclosures) are shown in Table 1. The laptop should be given a static IP address other than 192.168.1.101 and 192.168.1.100. Detailed instructions on how to configure a static laptop IP address can be found in Appendix A – Configure a Static Laptop IP Address.

Device	IP Address	Default Gateway	Subnet Mask
Thermal Camera	192.168.1.101	192.168.1.1	255.255.255.0
HD Camera	192.168.1.100		

Table 1 System IP Address Scheme

6. Computer Requirements

System requirements for the software are as follows:

- **Operating System:** Microsoft Windows 10.
- **Processor¹:** 32-bit or 64-bit Intel i5 or equivalent processor.
- **Memory:** 8GB RAM.
- **Monitor Resolution:** High Definition
- **Hard Drive Capacity:** >= 256GB

7. ETS (Evaluated Temperature Screening) Software Operation

This section of the User Guide details how to connect, configure, and operate the MODUM Screening application installed on the supplied laptop.

Hardware Setup

Before opening the software, please make sure that:

- MODUM device is powered on.
- MODUM is connected to the laptop via Ethernet cable, as shown in Figure 1.
- The laptop in use is connected to the same network/subnet as the MODUM camera and meets the specification detailed in Chapter 6.
- If an Ethernet-USB convertor is used, please check if the LED on the ethernet side is flashing constantly, as shown in Figure 2.
- The laptop's LAN connection has a static IP address. Instructions of setup a static IP can be found in Appendix A – Configure a Static Laptop IP Address.
- The Blackbody Temperature Reference device deployed with the FoV of the MODUM unit, at the distance of 2-5 meters away and set as 35°C.











Figure 2 USB-Ethernet converter with LED indicator on and flashing

¹ The CPU processor should have a benchmark score of greater than 7500 - www.cpubenchmark.net

Cameras Setup




If you are switching from Silent Sentinel's old solution to the new one, please make sure your thermal and daylight camera are correctly configured as shown below.

Thermal camera		
1	<p>Enter <i>http://(Thermal cam IP address)</i> in IE.</p> <p>Log in as admin/admin (default password)</p>	
2	<p>Open System – Encode Config – Encode Set.</p> <p>For <u>low resolution</u> camera:</p> <p>Resolution: 384 x 288</p> <p>Framerate: 50 fps</p> <p>Stream Value: 6144</p> <p>I Frame Interval: 50</p> <p>Click Confirm to save the settings.</p>	
	<p>For <u>high resolution</u> camera:</p> <p>Resolution: 640 x 512</p> <p>Framerate: 25 fps</p> <p>Stream Value: 6144</p> <p>I Frame Interval: 25</p> <p>Click Confirm to save the settings.</p>	
3	<p>Open System – Other.</p> <p>Tick Temperature Data Switch.</p> <p>For <u>dual light</u> unit (daylight + thermal):</p> <p>Set the framerate to 5 fps.</p>	


	<p>Click Confirm to save the settings.</p> <p>For <u>single light unit</u> (thermal only):</p> <p>Set the framerate to 20 fps.</p> <p>Click Confirm to save the settings.</p>	
<p>Daylight (Visual) camera</p> <ul style="list-style-type: none"> If a thermal-only unit is in used, you don't need to configure daylight camera. 		
<p>1</p>	<p>Enter <i>http://(Daylight cam IP address)</i> in IE.</p> <p>Log in as admin/admin (default password)</p>	
<p>2</p>	<p>Open Basic – Codec.</p> <p>Set H.264 resolution to 1280 x 720</p> <p>Set H.264 FPS to 25 fps.</p> <p>Click Submit to apply the settings.</p>	
<p>3</p>	<p>If the lighting condition in the room is not good enough to run face detection, increase the brightness setting.</p> <p>Open Camera – Exposure.</p> <p>Increase the brightness value accordingly.</p> <p>Click Submit to apply the settings.</p>	





7.1. First-time Setup

7.1.1. Import License

<p>1 Double-click the ETS shortcut on the desktop.</p> <p>OR open the SPxETS application from the SS_ETS folder.</p> <p>There are 32-bit and 64-bit executables. It is suggested to run the 64-bit version whenever possible (i.e. not on a 32-bit only OS).</p>	 <table border="1" data-bbox="691 510 1350 757"> <thead> <tr> <th>Name</th> <th>Date modified</th> <th>Type</th> <th>Size</th> </tr> </thead> <tbody> <tr> <td>cp-spx.lic</td> <td>04/06/2020 10:16</td> <td>License</td> <td>1 KB</td> </tr> <tr> <td>ETS_32bit</td> <td>18/06/2020 21:54</td> <td>Application</td> <td>36,792 KB</td> </tr> <tr style="border: 2px solid red;"> <td>ETS_64bit</td> <td>18/06/2020 23:13</td> <td>Application</td> <td>40,240 KB</td> </tr> <tr> <td>logo1</td> <td>18/06/2020 16:40</td> <td>BMP File</td> <td>29,298 KB</td> </tr> <tr> <td>logo2</td> <td>18/06/2020 16:39</td> <td>BMP File</td> <td>10,039 KB</td> </tr> <tr> <td>SPxETS</td> <td>19/06/2020 13:35</td> <td>RPI File</td> <td>25 KB</td> </tr> <tr> <td>SPxWizETSSetup</td> <td>11/06/2020 18:16</td> <td>XML Document</td> <td>6 KB</td> </tr> </tbody> </table>	Name	Date modified	Type	Size	cp-spx.lic	04/06/2020 10:16	License	1 KB	ETS_32bit	18/06/2020 21:54	Application	36,792 KB	ETS_64bit	18/06/2020 23:13	Application	40,240 KB	logo1	18/06/2020 16:40	BMP File	29,298 KB	logo2	18/06/2020 16:39	BMP File	10,039 KB	SPxETS	19/06/2020 13:35	RPI File	25 KB	SPxWizETSSetup	11/06/2020 18:16	XML Document	6 KB
Name	Date modified	Type	Size																														
cp-spx.lic	04/06/2020 10:16	License	1 KB																														
ETS_32bit	18/06/2020 21:54	Application	36,792 KB																														
ETS_64bit	18/06/2020 23:13	Application	40,240 KB																														
logo1	18/06/2020 16:40	BMP File	29,298 KB																														
logo2	18/06/2020 16:39	BMP File	10,039 KB																														
SPxETS	19/06/2020 13:35	RPI File	25 KB																														
SPxWizETSSetup	11/06/2020 18:16	XML Document	6 KB																														
<p>2 If a license is absent or invalid, it will prompt for the MAC address to generate a license for.</p> <p>Use the form below to request a license: https://form.jotformeu.com/201672508535354</p>																																	
<p>3 After receiving the license associated to the unique MAC address, <u>rename the license as "cp-spx.lic"</u> and <u>place it in the application folder.</u></p>																																	
<p>4 Now you should be able to run ETS as normal.</p>																																	

7.1.2. Open the Software



<p>1 Double-click the ETS shortcut on the desktop.</p> <p>OR open the SPxETS application from the SS_ETS folder.</p> <p>There are 32-bit and 64-bit executables. It is suggested to run the 64-bit version whenever possible (i.e. not on a 32-bit only OS).</p>	 <table border="1" data-bbox="624 1662 1350 1908"> <thead> <tr> <th>Name</th> <th>Date modified</th> <th>Type</th> <th>Size</th> </tr> </thead> <tbody> <tr> <td>cp-spx.lic</td> <td>04/06/2020 10:16</td> <td>License</td> <td>1 KB</td> </tr> <tr> <td>ETS_32bit</td> <td>18/06/2020 21:54</td> <td>Application</td> <td>36,792 KB</td> </tr> <tr style="border: 2px solid red;"> <td>ETS_64bit</td> <td>18/06/2020 23:13</td> <td>Application</td> <td>40,240 KB</td> </tr> <tr> <td>logo1</td> <td>18/06/2020 16:40</td> <td>BMP File</td> <td>29,298 KB</td> </tr> <tr> <td>logo2</td> <td>18/06/2020 16:39</td> <td>BMP File</td> <td>10,039 KB</td> </tr> <tr> <td>SPxETS</td> <td>19/06/2020 13:35</td> <td>RPI File</td> <td>25 KB</td> </tr> <tr> <td>SPxWizETSSetup</td> <td>11/06/2020 18:16</td> <td>XML Document</td> <td>6 KB</td> </tr> </tbody> </table>	Name	Date modified	Type	Size	cp-spx.lic	04/06/2020 10:16	License	1 KB	ETS_32bit	18/06/2020 21:54	Application	36,792 KB	ETS_64bit	18/06/2020 23:13	Application	40,240 KB	logo1	18/06/2020 16:40	BMP File	29,298 KB	logo2	18/06/2020 16:39	BMP File	10,039 KB	SPxETS	19/06/2020 13:35	RPI File	25 KB	SPxWizETSSetup	11/06/2020 18:16	XML Document	6 KB
Name	Date modified	Type	Size																														
cp-spx.lic	04/06/2020 10:16	License	1 KB																														
ETS_32bit	18/06/2020 21:54	Application	36,792 KB																														
ETS_64bit	18/06/2020 23:13	Application	40,240 KB																														
logo1	18/06/2020 16:40	BMP File	29,298 KB																														
logo2	18/06/2020 16:39	BMP File	10,039 KB																														
SPxETS	19/06/2020 13:35	RPI File	25 KB																														
SPxWizETSSetup	11/06/2020 18:16	XML Document	6 KB																														





<p>2 When first run, it should prompt you to run the wizard to specify which camera model you are using.</p>	 <p>The image shows a dialog box titled "SPxETS Configuration Error" with a yellow warning icon. The text inside says "Please run the setup wizard to specify the camera type." There is an "OK" button at the bottom right, which is highlighted with a red rectangle.</p>
<p>3 Allow all network access if Windows Security Alert pops up.</p>	 <p>The image shows a "Windows Security Alert" dialog box. The title bar says "Windows Security Alert". The main text says "Windows Defender Firewall has blocked some features of this app". Below this, it lists details for "SPxETS" by "Cambridge Pixel Ltd." and provides the file path. There are two checkboxes under "Allow SPxETS to communicate on these networks": "Private networks, such as my home or work network" and "Public networks, such as those in airports and cafés (not recommended because these networks often have little or no security)". Both checkboxes are checked and highlighted with a red rectangle. At the bottom right, there is an "Allow access" button, also highlighted with a red rectangle, and a "Cancel" button.</p>
<p>4 Acknowledge the Disclaimer.</p>	 <p>The image shows a "Disclaimer" dialog box. The title bar says "Disclaimer". The main text is a "WARNING REGARDING CONDITIONS OF USE" and includes several paragraphs of text regarding the device's use for medical diagnosis. At the bottom center, there is an "OK" button, which is highlighted with a red rectangle.</p>
<p>5 The home page with video display should be as per image on the right.</p>	 <p>The image shows a screenshot of the SPxETS home page. The top left corner has the "SPxETS SILENT SENTINEL" logo. The main area is a video display showing two camera feeds of a retail store interior. The left feed shows a person walking through an aisle, and the right feed shows a different aisle. The video player has a timestamp of "2020/06/19 11:39:03". At the bottom, there is a taskbar showing the system tray with a clock and other icons.</p>

7.1.3. Admin Login & Full Control Panel

<p>1 Click the Admin button.</p> <p>Default password: admin</p>	
<p>2 Click the Full button to display all the control panel buttons.</p>	
<p>3 Home page with full control panel is shown as per image.</p>	







7.1.4. Select Thermal Camera Type





<p>1 Log in as admin</p>	
<p>2 Open the File drop-down menu.</p> <p>Select Setup Wizard from the dropdown menu.</p>	

<p>3 Keep clicking Next until you arrive at the Camera page.</p> <p>Select the camera type being used: dual light or single head.</p> <p>Select the camera model being used: FD384H (low resolution) or FD640H (high resolution).</p>	
<p>4 Keep clicking Next until you arrive at the Finished page.</p> <p>Click Finish.</p>	
<p>5 Save the .rpi file.</p>	
<p>6 Click Yes to restart the application.</p>	

7.1.5. Offset and Alignment Nudging (Dual-light system only)

<p>1</p>	<ul style="list-style-type: none"> • Measure the distance between blackbody and camera (recommended distance: 2-5m). • Avoid placing blackbody at the edge of FOV. • Make sure you have set the camera type as instructed in 7.1.4. • For single light MODUM unit (i.e. thermal only), you can skip the alignment step.
----------	---






2	<p>Open Setting windows.</p>	
3	<p>Enter the distance between the camera and blackbody as Reference Range.</p> <p>Close the window to apply the setting.</p>	
4	<p>Show the Full interface</p>	
5	<p>Switch to Side-by-Side (thermal-daylight) display.</p>	
6	<p>Enable BB and BB-E.</p>	
7	<p>Draw a small rectangle to cover around 30% of the blackbody area in the thermal stream.</p>	

		
8	Disable BB-E .	
9	Use the Nudge buttons (L/R/U/D) to align the <u>yellow</u> rectangle in the <u>daylight</u> stream to cover the same area as the <u>purple</u> box thermal display.	
10	Click Save to save the configuration.	

7.1.6. Set Region of Interest (ROI)

Face detection is only applicable within the region of interest. Setting a proper ROI can reduce the CPU usage and guarantee the face detection performance.

1	Open daylight-only or side-by-side (Daylight-Thermal) display. * For single-head unit, you will not see this option.	
---	---	--

2	<p>Enable ROI and ROI-E.</p>		
3	<p>Draw the area of interest in daylight display.</p> <p>Note: If the ROI is too large, the face detection ability might be compromised.</p> <p>A recommended size for ROI is shown as per image.</p>		
4	<p>Disable ROI-E.</p>		
5	<p>Click Save to save the configuration.</p>		

7.1.7. Set background image


This button is only displayed if a thermal-only camera is configured (i.e. not a combined daylight/thermal video camera).













If the operator notices poor performance (for example, because a sudden change has happened - such as the camera being moved without rebooting or a new object being placed into view), then the **Reset B/G** button can be used to immediately reset the background image.














It should only be used with a “clean” view (with no people in view, because those people will not be detected).



7.2. Home Screen Brief Introduction







Title	Description
	Admin log in. Logging in enables access to more advanced control.
	Show the full control panel display.
	Save the current configuration.
	To open the setting window.
	When the software encounters an error message, this button will appear. Press F8 to check the error logs. Clicking the button acknowledges the error.
	Nudge to align daylight and thermal display for correct mapping.
	Spot measurement (cursor reading)
	Face bounding box
	Pic-in-Pic display
	Overlay text
	Region of Interest display
	Draw the region of interest





	<p>Alarm alert threshold and operational status.</p>
	<p>Freeze thermal display</p>
	<p>Auto focus the thermal lens.</p>
	<p>Colour palette: White Hot, Black Hot, RGB Hot.</p>
	<p>Enable/Disable blackbody correction.</p>
	<p>Draw blackbody area.</p>
	<p>This button is shown when BB-E is enabled, and a blackbody obstruction error has occurred. Pressing this icon acknowledges the error and resume other functions.</p>
	<p>Enable/Disable Temperature compensation.</p>
 (Dual light system only)	<p>Video display layout options.</p>
 (Single light system only)	<p>Reset background image for thermal detection.</p>
	<p>Display thumbnails and data from alarms.</p>
	<p>Region of interest where the camera will check for faces</p>
	<p>Blackbody area where the camera will reference temperature from.</p>



7.3. Basic Operations

7.3.1. Set Blackbody Area






1	Make sure that both streams are aligned. See 7.1.5 above for details.	
2	Enable BB and BB-E .	
3	Draw a <u>small</u> rectangle at the centre of the blackbody area in the Thermal stream's FOV.	
4	Disable BB-E .	
5	Click Save to save the configuration.	

7.3.2. Set Region of Interest (ROI)

1	Make sure that both streams are aligned. See 7.1.5 above for details.	
2	Open daylight-only or side-by-side (Daylight-Thermal) display. * For single-head unit, you will not see this option.	 
3	Enable ROI and ROI-E .	
4	Draw the area of interest in daylight display. Note: If the ROI is too large, the face detection ability might be compromised. A recommended size for ROI is shown as per image.	



5	Disable ROI-E .	
6	Click Save to save the configuration.	

7.3.3. Change Text size

1	Log in as admin	
2	Click the Full button to display all the control panel buttons.	
3	Click Settings to open the configuration window.	
4	<p>Under the tab Misc, set the Font Size for temperature data display.</p> <p>Close the window to apply the settings.</p>	
5	Click Save to save the configuration	





7.3.4. Change log in password



1	Log in as admin .	
---	--------------------------	--

2	<p>Open the File drop-down menu.</p> <p>Select Set Admin Password from the dropdown menu.</p>		
3	<p>Enter the new password.</p> <p>Click OK to save and apply the setting.</p>		



7.3.5. Set IP Address for Video Source

The following steps show how to change the IP of video source. It does NOT change the camera's IP address. To change camera's IP address, one must go to Web GUI to do so.

1	<p>Log in as admin</p>		
2	<p>Open the File drop-down menu.</p> <p>Select Setup Wizard from the dropdown menu.</p>		
3	<p>Keep clicking Next until you arrive at the Video page.</p> <p>Type the IP addresses of the video stream sources.</p>		
4	<p>Keep clicking Next until you arrive at the Finished page.</p> <p>Click Finish.</p>		

5	Save the .rpi file.	
6	Click Yes to restart the application.	

7.3.6. Full screen display

1	Log in as admin .	
2	Select View menu. Select Full Screen from the dropdown menu. Or press F11 .	







7.3.7. Disable Blackbody Calibration (not recommended)

The MODUM software uses the blackbody temperature reading as a reference. It is strongly advised to keep this function enabled at all times.




1	Log in as admin	
2	Disable the BB button – not recommended.	

7.3.8. Change Blackbody Temperature (not recommended)





As the blackbody provided by Silent Sentinel is set to a fixed temperature of 35°C by default, it is suggested to keep the blackbody temperature value as 35°C in the ETS software.

<p>1 Log in as admin</p>	
<p>2 Select File menu. Select Setup Wizard from the dropdown menu.</p>	
<p>3 Keep clicking Next until you arrive at the Blackbody page. Enter the temperature that matches the blackbody reference value.</p>	
<p>4 Keep clicking Next until you arrive at the Finished page. Click Finish.</p>	
<p>5 Save the .rpi file.</p>	
<p>6 Click Yes to restart the application.</p>	

7.3.9. Remove Blackbody Error







<p>1 When the blackbody is not aligned with the marked area set by ETS, a warning message will overlay on the video display, as per image.</p> <p>When this message shows up, all temperature-related service will stop, e.g. face detection, cursor reading etc.</p>	
<p>2 The error can be removed by redrawing the blackbody area. Detailed instructions can be found in 7.3.1.</p>	
<p>3 If the blackbody area is correct, click BB-R to acknowledges the error and resume other functions.</p> <p>Note that BB-R only appear when BB-E is enabled.</p>	

7.3.10. Configure Audible Alarm


<p>1 Log in as admin</p>	
<p>2 Click the Full button to display all the control panel buttons.</p>	
<p>3 Click Settings to open the configuration window.</p>	
<p>4 Under the section Audible Alarms:</p> <p>Tick/Untick <input checked="" type="checkbox"/> Audible Alarms to enable/disable a sound notification for <u>every alert triggered</u>.</p> <p>Tick/Untick <input type="checkbox"/> Audible All Clears to enable/disable a sound notification for <u>every non-fever detection</u>.</p>	

5	Click Save to save the configuration.	
---	--	---

7.3.11. Configure data logging/saving

1	Log in as admin	 
2	Enable full control panel	
3	Click Settings	
4	<p>Under the section Logging:</p> <p>Tick/Untick <input type="checkbox"/> Log Alarms To Disk to enable/disable logging of <i>all detected fever</i>. Information logged includes Date, Time, Status, Temperature, Threshold and screen coordinated of the detected face.</p> <p>Tick/Untick <input type="checkbox"/> Log All Detections To Disk to enable/disable logging for <i>all detected face</i>. Same information is saved as detailed.</p> <p>Tick/Untick <input type="checkbox"/> Save Snapshots To Disk to enable/disable saving a snapshot of the <i>fevered face</i>.</p>	
5	Click Save to save the configuration.	


7.3.12. Check logged data

1	Data logging can be turned on/off following steps in 7.3.11.	
2	<p>Navigate to the folder SS_ETTS.</p> <p>Open the .csv file "SPxETS-Log-Date-Time.csv"</p>	






<p>3</p>	<p>An example of log (Alarm Only) as per image.</p> <p>X and Y coordinates are mapped to have the bottom-left corner be (0,0) and top-right corner be (1,1).</p> <p>The values represent distance in percentages of the dimensions of the snapshot (Example: the X and Y coordinates of the centre in a 1920x1080 snapshot would be (0.5,0.5)).</p> <p>The width and height are not coordinates, but instead perimeter (in percentage of snapshot dimensions) of the area detected with a face in it starting at the bottom-left corner as the point given with the coordinates.</p>	<table border="1"> <thead> <tr> <th>Date</th> <th>Time</th> <th>Status</th> <th>Temperature(C)</th> <th>Threshold(C)</th> <th>X</th> <th>Y</th> <th>W</th> <th>H</th> <th>I</th> <th>J</th> <th>K</th> </tr> </thead> <tbody> <tr><td>18/06/2020</td><td>15:59:02</td><td>ALARM</td><td>38.5</td><td>37.3</td><td>0.61</td><td>0.46</td><td>0.1</td><td>0.1</td><td>0.2</td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>15:59:06</td><td>ALARM</td><td>36.7</td><td>36.2</td><td>0.6</td><td>0.46</td><td>0.1</td><td>0.1</td><td>0.2</td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>15:59:14</td><td>ALARM</td><td>39.4</td><td>36.2</td><td>0.63</td><td>0.47</td><td>0.1</td><td>0.1</td><td>0.21</td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>15:59:26</td><td>ALARM</td><td>39.5</td><td>36.2</td><td>0.7</td><td>0.49</td><td>0.09</td><td>0.21</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>15:59:29</td><td>ALARM</td><td>36.2</td><td>36.2</td><td>0.59</td><td>0.44</td><td>0.09</td><td>0.2</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>15:59:38</td><td>ALARM</td><td>41.6</td><td>39.8</td><td>0.62</td><td>0.45</td><td>0.1</td><td>0.2</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>15:59:40</td><td>ALARM</td><td>39.8</td><td>36.4</td><td>0.6</td><td>0.32</td><td>0.04</td><td>0.09</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:01:39</td><td>ALARM</td><td>36.4</td><td>36.4</td><td>0.47</td><td>0.46</td><td>0.1</td><td>0.2</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:01:46</td><td>ALARM</td><td>36.4</td><td>36.4</td><td>0.41</td><td>0.47</td><td>0.13</td><td>0.23</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:01:57</td><td>ALARM</td><td>36.3</td><td>36.3</td><td>0.17</td><td>0.47</td><td>0.11</td><td>0.21</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:02:03</td><td>ALARM</td><td>36.2</td><td>36.2</td><td>0.17</td><td>0.47</td><td>0.11</td><td>0.21</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:02:29</td><td>ALARM</td><td>36.1</td><td>36.1</td><td>0.21</td><td>0.52</td><td>0.11</td><td>0.19</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:02:38</td><td>ALARM</td><td>36.4</td><td>36.4</td><td>0.21</td><td>0.52</td><td>0.1</td><td>0.19</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:06:02</td><td>ALARM</td><td>36.6</td><td>36.6</td><td>0.74</td><td>0.27</td><td>0.04</td><td>0.26</td><td></td><td></td><td></td></tr> <tr><td>18/06/2020</td><td>16:06:08</td><td>MSG</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>End of log</td></tr> </tbody> </table>	Date	Time	Status	Temperature(C)	Threshold(C)	X	Y	W	H	I	J	K	18/06/2020	15:59:02	ALARM	38.5	37.3	0.61	0.46	0.1	0.1	0.2			18/06/2020	15:59:06	ALARM	36.7	36.2	0.6	0.46	0.1	0.1	0.2			18/06/2020	15:59:14	ALARM	39.4	36.2	0.63	0.47	0.1	0.1	0.21			18/06/2020	15:59:26	ALARM	39.5	36.2	0.7	0.49	0.09	0.21				18/06/2020	15:59:29	ALARM	36.2	36.2	0.59	0.44	0.09	0.2				18/06/2020	15:59:38	ALARM	41.6	39.8	0.62	0.45	0.1	0.2				18/06/2020	15:59:40	ALARM	39.8	36.4	0.6	0.32	0.04	0.09				18/06/2020	16:01:39	ALARM	36.4	36.4	0.47	0.46	0.1	0.2				18/06/2020	16:01:46	ALARM	36.4	36.4	0.41	0.47	0.13	0.23				18/06/2020	16:01:57	ALARM	36.3	36.3	0.17	0.47	0.11	0.21				18/06/2020	16:02:03	ALARM	36.2	36.2	0.17	0.47	0.11	0.21				18/06/2020	16:02:29	ALARM	36.1	36.1	0.21	0.52	0.11	0.19				18/06/2020	16:02:38	ALARM	36.4	36.4	0.21	0.52	0.1	0.19				18/06/2020	16:06:02	ALARM	36.6	36.6	0.74	0.27	0.04	0.26				18/06/2020	16:06:08	MSG									End of log
Date	Time	Status	Temperature(C)	Threshold(C)	X	Y	W	H	I	J	K																																																																																																																																																																																							
18/06/2020	15:59:02	ALARM	38.5	37.3	0.61	0.46	0.1	0.1	0.2																																																																																																																																																																																									
18/06/2020	15:59:06	ALARM	36.7	36.2	0.6	0.46	0.1	0.1	0.2																																																																																																																																																																																									
18/06/2020	15:59:14	ALARM	39.4	36.2	0.63	0.47	0.1	0.1	0.21																																																																																																																																																																																									
18/06/2020	15:59:26	ALARM	39.5	36.2	0.7	0.49	0.09	0.21																																																																																																																																																																																										
18/06/2020	15:59:29	ALARM	36.2	36.2	0.59	0.44	0.09	0.2																																																																																																																																																																																										
18/06/2020	15:59:38	ALARM	41.6	39.8	0.62	0.45	0.1	0.2																																																																																																																																																																																										
18/06/2020	15:59:40	ALARM	39.8	36.4	0.6	0.32	0.04	0.09																																																																																																																																																																																										
18/06/2020	16:01:39	ALARM	36.4	36.4	0.47	0.46	0.1	0.2																																																																																																																																																																																										
18/06/2020	16:01:46	ALARM	36.4	36.4	0.41	0.47	0.13	0.23																																																																																																																																																																																										
18/06/2020	16:01:57	ALARM	36.3	36.3	0.17	0.47	0.11	0.21																																																																																																																																																																																										
18/06/2020	16:02:03	ALARM	36.2	36.2	0.17	0.47	0.11	0.21																																																																																																																																																																																										
18/06/2020	16:02:29	ALARM	36.1	36.1	0.21	0.52	0.11	0.19																																																																																																																																																																																										
18/06/2020	16:02:38	ALARM	36.4	36.4	0.21	0.52	0.1	0.19																																																																																																																																																																																										
18/06/2020	16:06:02	ALARM	36.6	36.6	0.74	0.27	0.04	0.26																																																																																																																																																																																										
18/06/2020	16:06:08	MSG									End of log																																																																																																																																																																																							

7.3.13. Check alarm snapshots


<p>1</p>	<p>Snapshot saving can be turned on/off following steps in 7.3.11.</p>	
<p>2</p>	<p>Navigate to the SS_ETS/Snapshots folder.</p>	


<p>3 The snapshots are from <u>alarm only</u>.</p> <p>Each picture is named with capture date, time, temperature and source stream.</p>	
---	--

7.3.14. Change temperature threshold


<p>1 Log in as admin</p>	
<p>2 Enable full control panel</p>	
<p>3 Click Settings</p>	
<p>4 Under the Temperatures section, set the min and max temperature of objects that the software can recognize as a face.</p> <p>Adjust the alarm threshold to trigger after a face above the threshold value is detected.</p>	
<p>5 Click Save to save the configuration.</p>	



7.3.15. Configure Face Detection Settings

<p>1 Log in as admin</p>	
---------------------------------	--






2	Enable full control panel	Full
3	Click Settings	Settings
4	<p>Under the section Face Detection, set the process interval (unit: <i>frames</i>) and minimum confidence as per image.</p> <p>Processing interval determines the frequency (measured in <i>frames</i>) of mapping between daylight and thermal stream.</p> <p>Minimum confidence defines the confidence (measured in percentage) in face detection.</p> <p>Recommended value: <i>Dual light system:</i> Processing Interval: 6-8 Minimum Confidence: 0.2</p> <p><i>Single light system:</i> Processing Interval: 1 Minimum Confidence: 0.4-0.5</p>	
5	Click Save to save the configuration.	Save

7.3.16. Change Temperature Scale



1	Log in as admin	
2	Enable full control panel	Full
3	Click Settings	Settings

<p>4 Under Misc tab, select the temperature scale.</p> <p>Close the window to apply any setting.</p>	
<p>5 Click Save to save the configuration.</p>	


7.3.17. Face Detection Data Overlay Options



<p>1 Log in as admin</p>	
<p>2 Enable full control panel</p>	
<p>3 Click Settings</p>	
<p>4 Under the Misc tab, tick items in the Display Options to be included in the face bounding box.</p> <p>Set the size for the displayed text/data.</p> <p>Close the setting window to apply any settings.</p>	
<p>5 Click Save to save the configuration.</p>	

7.3.18. Configure Blackbody Obstruction Detection

1	Log in as admin	Admin	
2	Enable full control panel	Full	
3	Click Settings	Settings	
4	Under the Misc tab, set the value for standard deviation in the Blackbody section. Recommend value: <u>0.05</u> . Close the setting window to apply any settings.		
5	Click Save to save the configuration.	Save	

7.3.19. Configure thermal Non-Uniformity Correction (NUC)




1	Log in as admin	Admin	
2	Enable full control panel	Full	
3	Click Settings	Settings	

4	<p>Under the Misc tab, tick NUC Auto if you wish to let the camera conduct self-calibration automatically. Set the interval (measured in sec).</p> <p>Unticking NUC Auto turns off auto NUC.</p> <p>Close the setting window to apply any settings.</p>	
5	Click Save to save the configuration.	

7.3.20. Auto focus the thermal lens

1	Click AF button to start auto focusing the <i>thermal</i> lens.	
---	--	--

7.3.21. Change colour palette

1	Enable full control panel	
2	Select the colour palette to display for thermal stream: White Hot , Black Hot and RGB Hot .	
3	Click Save to save the configuration.	



7.3.22. Temperature Compensation Mode

SS ETS uses a temperature compensation algorithm to calculate the core body temperature when given the temperature reading the face skin. The compensation mode can be toggled via following steps.




1	Enable full control panel	
2	Enable/Disable COMP button.	

7.3.23. Clear data (error/thumbnails)

1	Log in as admin	
---	------------------------	--







2	<p>Select Tools in the top menu bar.</p> <p>Click Clear Error to erase all the <u>logged message</u>.</p>	
3	<p>Click Clear Thumbnails to erase all the <u>snapshots</u> stored on the right-hand side.</p>	
4	<p>Note that this step only clears the data stored on the software. It does NOT delete data stored on the disk.</p>	

7.3.24. Take screenshot

1	<p>Log in as admin</p>	
2	<p>Select Tools in the top menu bar.</p> <p>Click Grab Screen to take a screenshot of the application window.</p> <p>OR press Ctrl + G.</p>	
3	<p>Screenshots are automatically saved in the same directory as SS ETS application.</p>	






7.3.25. Hide thumbnail display


1	<p>Log in as admin.</p>	
---	--------------------------------	--

2	<p>Select File in the top menu bar.</p> <p>Click Parameter Control to open the Parameter Configuration window.</p>		
3	<p>In Parameter Configuration window, type Application.Layout in the Parameter field.</p> <p>Set value 6 for <u>Daylight-only</u> display.</p>		
4	<p>In Parameter Configuration window, type Application.Layout in the Parameter field.</p> <p>Set value 7 for <u>Thermal-only</u> display.</p>		
5	<p>OR select Side-by-Side display to cover the thumbnail display.</p>		





7.4. Advance configuration



7.4.1. Use Modbus for alarm output

1	Log in as admin	
2	<p>Select File menu.</p> <p>Select Setup Wizard from the dropdown menu.</p>	
3	<p>Keep clicking Next until you arrive at the Modbus page.</p> <p>Tick to confirm a Modbus module is being used.</p> <p>Set the IP address and relevant information.</p>	
4	<p>Keep clicking Next until you arrive at the Finished page.</p> <p>Click Finish.</p>	
5	Save the .rpi file.	




6	Click Yes to restart the application.	
---	--	--

7.4.2. Use of EdgeVis

1	Log in as admin	
2	Select File menu. Select Setup Wizard from the dropdown menu.	
3	Keep clicking Next until you arrive at the EdgeVis page. Tick to confirm an EdgeVis module is being used. Set the IP address, Port number and Password.	
4	Keep clicking Next until you arrive at the Finished page. Click Finish .	

5	Save the .rpi file.	
6	Click Yes to restart the application.	

7.4.3. View message log

1	Log in as admin .	
2	Select View in the top menu bar. Click Message Window to open the message log.	
3	An example of Message log is as per image.	 <pre> Jun 19 13:40:09: SPxETS V1.84.2-devK. Jun 19 13:40:09: License ID 110-0364 Jun 19 13:40:11: Exited admin mode. Jun 19 13:40:16: SPx Warning - AV Error (#2500), args 219744, 221184, SPxAVProcTempExtract::Process, Payload too small. Jun 19 13:40:19: Entered admin mode. Jun 19 13:40:33: SPx Warning - AV Black Body (#2695), args 1, 0, Black body out of spec (stddev 4.535, mean 34.7). Jun 19 13:40:33: SPx Info - AV Black Body (#2695), args 5, 0, Black body in spec (stddev 0.026, mean 35.1). Jun 19 13:41:17: SPx Warning - AV Error (#2500), args 215424, 221184, SPxAVProcTempExtract::Process, Payload too small. Jun 19 13:42:20: SPx Warning - AV Error (#2500), args 212544, 221184, SPxAVProcTempExtract::Process, Payload too small. Jun 19 13:43:23: SPx Warning - AV Error (#2500), args 211104, 221184, SPxAVProcTempExtract::Process, Payload too small. Jun 19 13:44:11: SPx Warning - AV Black Body (#2695), args 1, 0, Black body out of spec (stddev 0.052, mean 35.0). Jun 19 13:44:11: SPx Info - AV Black Body (#2695), args 32, 0, Black body in spec (stddev 0.023, mean 35.0). Jun 19 13:44:11: SPx Warning - AV Black Body (#2695), args 1, 0, Black body out of spec (stddev 0.067, mean 35.0). Jun 19 13:44:12: SPx Info - AV Black Body (#2695), args 17, 0, Black body in spec (stddev 0.048, mean 34.7). Jun 19 13:44:12: SPx Warning - AV Black Body (#2695), args 1, 0, Black body out of spec (stddev 0.067, mean 34.9). Jun 19 13:44:12: ALARM: -40.1°C (current threshold 37.3°) Jun 19 13:44:13: SPx Info - AV Black Body (#2695), args 50, 0, Black body in spec (stddev 0.042, mean 35.1). </pre>

7.4.4. Advanced parameter control



Advice not to change. If necessary, consult Silent Sentinel before modifying. Changes without any consultation may result in a malfunction.

8. Common problems and solutions

8.1. Face detection not working

A. Possible cause: poor lighting condition

Solution:

<p>1 Enter http://(Daylight cam IP address) in IE.</p> <p>Log in as admin/admin (default password)</p>	
<p>2 Open Camera – Exposure.</p> <p>Increase the brightness value accordingly.</p> <p>Click Submit to apply the settings.</p>	

B. Possible cause: ROI too large

Solution: re-draw ROI with a smaller size. Detailed steps can be found in 7.3.2 above.

8.2. Face bounding box lagging

A. Possible cause: ROI too large

Solution: re-draw ROI with a smaller size. Detailed steps can be found in 7.3.2 above.

B. Possible cause: face processing interval too long.

Solution: reduce the face process interval by following steps in 7.3.15. Beware that reducing the interval will result increase in CPU usage. Please make sure there is enough CPU resource available on PC.


C. Possible cause: Single light system in used (i.e. thermal-only)


Solution: Add the following line at the end of SPxETS.rpi file located in /Config folder:

```
Video1.MetadataDelay = 4 # frames
```

8.3. Thermal-only detection picking up non-face objects (e.g. arms, blackbody...)

A. Solution:


- When the background is “clean” (i.e. no one in the FOV), press  to reset the background image.
- Increase the confidence threshold for face detection.




- c. Reset the Region of Interest (ROI) to exclude body parts.

Appendix A – Configure a Static Laptop IP Address


Select the Start Button and Type 'Control Panel'




Select Network and Sharing Center




Select Adapter Options



Double Click on the relevant network adapter



Double Click on 'Internet Protocol Version 4 (TCP/IPv4)



Select the radio button named 'Use the following IP address'

Enter the information shown in the image to the right.

Select 'Okay' and the 'Okay' on the sub menu.

